

Safety relays PNOZelog


PILZ
THE SPIRIT OF SAFETY

► Safety relays PNOZelog – Solid-state safety!



- The innovative PNOZelog product range combines the experience of electromechanical safety relays with the advantages of modern electronics
- The right PNOZelog for every safety function
 - One to four safety functions can be monitored reliably
 - Save on wiring
 - Easy to link via logic operations such as AND/OR
 - Expanded diagnostics increase your machine's availability
 - Power-up tests, self-checking and runtime tests guarantee maximum safety

► PNOZelog – An overview of the features



- Long service life
- Expanded diagnostics
- Non-wearing
- AND/OR connections
- Compact
- Plug-in terminals (spring-loaded terminals, screw terminals)

Monitor two safety functions simultaneously with just a single unit.

Interconnect PNOZelog to form linked safety functions. Logic connections are available for this purpose. These logic AND/OR connections remove the need for additional wiring on the output. Both outputs on the PNOZelog units are free to use.

► Application areas for PNOZelog

Mobile applications

- Recycling machinery such as sieves, assembly lines and vibration plants
- Shredding plants

The PNOZelog combines several classic hard-wired functions within one elog solution, for example:

- Safety gate
- E-STOP
- Enabling switch
- etc.




► PNOZ e1p – Multifunctional PNOZelog




- One unit that can be applied universally; covers all safety applications from E-STOP through to light beam devices in all categories in accordance with EN ISO 13849-1 and EN 954-1
- Lower logistics costs thanks to a multifunctional product, which can be applied universally
- Simple product selection

► PNOZ e1.1p – PNOZelog with logic link function




- Functions are the same as the PNOZ e1p
- Additional logic AND/OR function

► PNOZ e1vp – PNOZelog with delay




- Functions are the same as the PNOZ e1.1p
- 2 types: Time range up to 10 s and up to 300 s
- Safe delay time, for which parameters can be set
- Safe instantaneous or delayed output with PI e (in accordance with EN ISO 13849-1) and Cat. 4 (in accordance with EN 954-1)
- 9 selectable times
- With logic AND/OR function

► PNOZ e2.1p – PNOZelog for two-hand




- Two-hand pushbuttons connected directly
- Requirement class IIIC EN 574
- Test pulse outputs
- Detection of shorts across contacts
- Simultaneity monitoring in accordance with EN 574
- With logic AND/OR function

► PNOZ e2.2p – PNOZelog for two-hand




- Two-hand pushbuttons connected directly
- Requirement class IIIA EN 574
- Test pulse outputs
- Detection of shorts across contacts
- Simultaneity monitoring in accordance with EN 574
- With logic AND/OR function

► PNOZ e3.1p – PNOZelog for safety gate monitoring




- Evaluation device for non-contact magnetic safety switches from the PSEN 2.x range
- In accordance with the standard EN 60947-5-3, the unit comprising PNOZ e3.1p and PSEN 2.x is classified as PDF-M with self monitoring for increased safety requirements
- With logic AND/OR function

► PNOZ e3vp – PNOZelog for safety gate monitoring with delay




- Functions are the same as the PNOZ e3.1p
- 2 types: Time range up to 10 s and up to 300 s
- Safe delay time, for which parameters can be set
 - Safe instantaneous or delayed output with Ple (in accordance with EN ISO 13849-1) and Cat. 4 (in accordance with EN 954-1)
- 9 selectable times
- With logic AND / OR function

▶ PNOZ e4.1p – PNOZelog for monitoring pressure sensitive mats



- ▶ Evaluation device for connection to Mayser SM/BK type safety mats
- ▶ Suitable as an evaluation device for connection to PSS/DIO/PNOZmulti
- ▶ For Category 4 in accordance with EN ISO 13849-1 and Category 3 in accordance with EN 954-1
- ▶ With logic AND/OR function

▶ PNOZ e4vp, 10 s – PNOZelog for monitoring pressure sensitive mats with delay



- ▶ Functions are the same as the PNOZ e4.1p
- ▶ Delay time range up to 10 s
- ▶ With logic AND / OR function

► PNOZ e5.11– The bi-functional PNOZelog



- Monitors 2 logically connected safety functions in one housing
- 2 N/C contacts per safety function
- Logic AND connection between the 2 safety functions
- One logic AND input to connect several PNOZelogs
- Each safety function has a separate signal output
- Less wiring needed, so less space is required in the control cabinet

► PNOZ e5.13p – The bifunctional PNOZelog



- Monitors 2 logically connected safety functions in one housing
- Safety functions N/C / N/O and N/C / N/C
- Logic AND connection between the 2 safety functions
- One logic AND input to connect several PNOZelogs
- Each safety function has a separate signal output
- Less wiring needed, so less space required in the control cabinet

► PNOZ e7p– PNOZelog for monitoring single light beam devices



- Connection option for E-STOP pushbuttons, safety gate limit switches, reset buttons
- Proximity switch evaluation devices, available with monitored or automatic reset
- One logic AND input
- Ability to connect up to 2 Pilz single light beam devices

► Safe power-up in conjunction with the safe line inspection device PLIDdys



- Line inspection device PLIDdys in combination with the evaluation device PNOZ e8.1p
- The safe line inspection device PLIDdys provides safe power-up on two-wire connections, providing maximum safety on long cable routes

**The 4-fold safety
of automation**

COMPONENTS
SYSTEMS
SERVICES

Technical Ecological
Personal Economical

Pilz Automation Safety, L.P.
7150 Commerce Blvd.
Canton, MI 48187
Tel.: +1 734 354-0272
Fax: +1 734 354-3355
info@pilzusa.com



Keep up-to-date on Pilz
www.pilz.us

PILZ
THE SPIRIT OF SAFETY

CMSE®, InduraNET p®, PAS4000®, PAScal®, PASconfig®, Pilz®, PIT®, PLID®, PMCPitego®, PMClendo®, PMD®, PMM®, PNOZ®, PNOZ® Prime®, PSEN®, PSS®, PVIS®, SafetyBUS p®, SafetyEYE®, SafetyNET p®, THE SPIRIT OF SAFETY®, are registered and protected trademarks of Pilz GmbH & Co. KG in some countries. We would point out that product features may vary from the details stated in this document, depending on the status at the time of publication and the scope of the equipment. We accept no responsibility for the validity, accuracy and entirety of the text and graphics presented in this information. Please contact our Technical Support if you have any questions.